

CABINET HANDLE CARE & MAINTENANCE

Cleaning Your Cabinet Handles & Knobs

Do not use caustic cleaners on any part of your cabinet handles and knobs.

Do not use harsh chemicals or any cleaning products containing abrasive powders.

Use a soft brush and/or damp cloth to wipe handles and knobs. Wipe dry. Do this regularly.

For more stubborn marks, use warm water and a mild soap such as dishwashing liquid. Wipe dry.

If Your Cabinet Handles & Knobs Loosen

If your cabinet handles and knobs have loosened a little, make sure to tighten the screws right away.

Handles and knobs that are not re-tightened will only become looser and will wear the screw holes, and possibly the cabinetry, to the point where handle may pull away and may not be able to be refastened.

Screws

FIT's cabinet handles are supplied with screws to suit 18mm board.

Screws are zinc coated M4, pozi flat combination drive, low profile flat head.

Should you need to replace them, ensure you use an appropriate option.