

# DRAWER CARE & MAINTENANCE

---

## Use and Maintenance

Take care to ensure items in drawers do not become entangled in the drawer runners.

Regularly remove crumbs, sticky residue or other matter from near and on runners using a soft brush or cloth.

Be familiar with the load capacity of your drawers and do not exceed it. (Load capacities for FIT's various drawer systems are on our website.)

When opening and closing your drawers or when putting items into them do not apply strong downward force as this may damage the runners.

Take care not to damage the painted surface of metal parts with hard or metallic objects. If you do chip the paint, it is recommended that the chip is repaired with a touch-up paint as recommended by a reputed paint supplier.

Using a product like anti slip matting is a great way to protect your drawers as it helps to prevent scratching and marking and may therefore extend the life of your drawers. (It also helps to stop items in the drawer from moving during drawer opening and closing, helping to prevent scratching and chipping of glassware, mugs etc).

## Cleaning Your Drawers

Do not use caustic cleaners on any part of your drawer.

Some dishwasher powders and laundry powders are particularly caustic, as are dry salt, salt water and any citrus juice. If they spill onto or into your drawers, remove the powder promptly with a vacuum cleaner, soft brush or or damp cloth taking care to re-wipe the surface clean after rinsing cloth free of substance and ensure it is dried well.

Painted steel parts – clean with a soft brush or cloth, using warm water and a mild soap such as dishwashing liquid, which will help break down any stains. Avoid harsh chemicals.

Powder coated aluminium parts - clean with a soft brush or cloth, using warm water and a mild soap such as dishwashing liquid, which will help break down any stains. Avoid harsh chemicals. Wiping with a microfibre cloth is also a good dusting/cleaning method.